Amcargobikes


Cargo bike enthusiast since 1992




Electric Cargo Bike Ultimate Harmony

Assembly Instructions

Read the manual carefully before starting the assembly. The bike is assembled in several different stages. It is important to read the operating instructions carefully before assembly begins, so the bike is mounted in the correct order. It is recommended to be two people to mount the cargo bike. Note that all nuts and screws on the bike must be tightened after about a month of use. Be sure to check all parts of the bike and tighten all screws and bolts.






Amcargobikes


Cargo bike enthusiast since 1992


As shown in Figure 2, with M6 large round cross head screw, connect the front, the middle, and the rear fixing plates to the bottom plate on the loading box and the loading box chassis, put the M6 washer, and screw on the M6 checknut (Note that please do not twist it too tight so that the fixing plates are removable and the loading box is adjustable.)



3


As shown in Figure 3, with an interlocking screw, connect the front and the rear boards of the loading box to the fixing plates of the loading box(As for the sizes of the screws, please refer to the loading box screw specification diagram), when connecting with the screws, please put the corresponding spare parts on as shown in Figure 3, please do not tighten the screw too much before all the screws are put and the bottom of the box is adjusted to its best position, then tighten the 12 M6 large round cross head screws on the bottom plate of the loading box, and last of all tighten all the interlocking screws on the loading box;





5

As shown in Figure 5, first connect the quick disassembling handles, the reflecting panels, the headlights, and the rainshed pendants to their corresponding positions on the loading box, when the rainshed pendants are fixed, please note that the seatbelts should be added both in the front and in the rear(The other end of the seatbelt should be connected to the corresponding holes in the cushion plate, as for the sizes of the screws, please refer to the loading box screw specification diagram), then install the handlebar and the shed poles(The inserted depth should be flush with the bottom of the casing), tighten the quick disassembling handle screws, and last of all organize the brake wires, the shift cables, and the power wiring harness, and you will complete your installation.





Cargo bike enthusiast since 1992

See link for assembly video of hydraulic brakes:

Tektro brakes

https://amladcyklar.se/wp-content/uploads/2020/06/Film-montering-af-hydraulik-bremser-Assembly-of-hydrolic-brakes.mov

Bengal Brakes

https://amcargobikes.co.uk/wp-content/uploads/2022/01/Bengal-montering-video-1.mp4

https://amcargobikes.co.uk/wp-content/uploads/2022/01/Bengal-montering-video-2.mp4