

ULTIMATE CURVE



ASSEMBLE MANUAL

Read and understand these instructions before you begin the assembly. The bike comes partly assembled, and it is important to read the manual carefully before starting assembly, so the bicycle will be assembled in the correct order. It is recommended to be two people to assemble the cargo bike. Be aware that the bike must be re-tightened after approx. 20 km. Make sure to check all parts of the bike and re-tighten all moving parts, including breaks, spokes, bolts and nuts.

Cargo bike enthusiast since 1992

Step 1: Mounting of fenders, front wheels and breaks

• When the parts have been taken out of the boxes and wrapping, place the front frame upside down on a table (<55 cm wide) - see picture 1A.



Picture 1A

• The two "stoppers" are mounted on the frame as shown on picture 1B and 1C.





Picture 1B

Picture 1C



The two front fenders is mounted using the four fender-fittings and the eight small allen key ٠ bolts, waschers and nuts - ses picture 1D and 1E.



- 2 pc. fenders
- 4 pc. fender fittings
 8 pc. allen key bolts
- 8 pc. washers
- 8 pc. lock nuts



Picture 1D



Picture 1E

The break discs are mounted on the front wheels - remember to match the direction of the discs • and the wheels. Ses picture 1F and 1G.











• The front wheels are mounted – see picture 1F and 1G. Notice the direction of the wheels – they must be mounted like shown in the pictures.





Picture 1F

Picture 1G

- The hydraulic break kit for the front breaks is mounted like shown in the pictures 1H, 1I and 1J.
- First the piece connecting the cables is mounted using the two blank bolts, washers and lock nuts.
- Secondly, the break calibers are mounted using the four black allen key bolts.
- The position of the break calibers versus the break discs are adjusted via the side-by-side adjustment bolts on the break caliber – see picture 1K and 1L. The break discs should in this way run freely without touching the break pads when the wheel is turned. It is however OK if there is a small "whisling" sound from the break when the wheel is turned – this will disappear after a few days of use.



- 1 pc. hydraulic break kit
- 2 pc. metalic bolts
- 2 pc. washers
- 2 pc. lock nuts
- 4 pc. black allan key bolts
- 4 pc. black washers



Picture 1H





Picture 1I



Picture 1K



Picture 1J



Picture 1L



• The hydraulic cables are stripped to the frame – ses picture 1M and 1N.



Picture 1M

Picture 1N

Step 2: Assemby of back frame and front frame

- The bearings should be lubricated with grease and the back frame and front frame is assembled with the main bolt and the bearings see picture 2A.
- The split is inserted see picture 2B.





Picture 2A

Picture 2B



Step 3: Assembly of the cargo bike box

• The corner brackets are mounted on the frame. The short brackets on the front of the bike and the long brackets at the handle bar. See picture 3A, 3B and 3C.



- 4 pc. corner brackets
- 8 pc. allen key bolts
- 8 pc. washers
- 8 pc. lock nuts



Picture 3A



Picture 3B

Picture 3C



• The bolts holding the canopy holders and the handle bar is mounted - see picture 3D and 3E.



- 6 pc. big allen key bolts
- 6 pc. nuts





Picture 3D

Picture 3E

٠ Hereafter, the side plates are mounted (picture 3F, 3G and 3H), the front- and back-plate (picture 3I, 3J and 3K) and the bottom plate (picture 3L and 3M).



- For the side plated:
- 10 pc. bolts
- 10 pc. washers
- 10 pc. round nuts



Picture 3G





Picture 3F

Cargo bike enthusiast since 1992



- For the front- and back plate:

- 10 pc. bolts
 10 pc. washers
 10 pc. round nuts



Picture 3J





Picture 3I



Picture 3K

- For the bottom plate: 4 pc. long bolts 4 pc. washers 4 pc. lock nuts





Picture 3L

Picture 3M



• The four bolts scuring the child seats are mounted – ses picture 3N and 3O.



- 4 pc. semi-long bolts
- 4 pc. washers
- 4 pc. lock nuts






Picture 3N

Picture 3O

• The stepping boards are mounted – see picture 3P and 3Q.



- 4 pc. short bolts
- 4 pc. washers
- 4 pc. round nuts



Picture 3P

Page 10

Cargo bike enthusiast since 1992

• The reflectors are mounted on the front- and back plate – see picture 3R and 3S.



Picture 3S

• The canopy fittings are mounted on the side plates – see picture 3T.



- 8 pc. canopy fittings
- 8 pc. allen key bolts with female thread
- 8 pc. allen key bolts with male thread
- 8 pc. washers for bolts with male thread
- 8 pc. big washers for bolts female thread



Picture 3T



The child seats are mounted - see picture 3U. •



- 4 pc. long bolts
 4 pc. washers
 4 pc. lock nuts



Picture 3U

The belts and the fitting holding the cables to the handle bar is mounted - see picture 3V and 3X. •







Picture 3V



Step 4: Mounting of the rest of the equipment

• The pedals are mounted - see picture 4A





• The saddle is mounted – see picture 4B and 4C

Picture 4A







Picture 4B

Cargo bike enthusiast since 1992

- The handle bar is mounted. The gearshift should be placed on the right side of the handle bar and the two break handles on the left and right side respectively see picture 5D and 5E.
- The handle bar hight is adjusted and the bolts are tightened see picture 4F.
- The cables for the breaks are connected see picture 4G.





Picture 4E



Picture 4G



Picture 4D



Picture 4F



• The hydraulic break cables are pulled through the handle bar – the front break cable through the left side and and the back break cable through the right side – see picture 4H and 4I.





Picture 4I

- Picture 4H
- The hydraulic break cables are mounted in the break handles First, the plug is removed from the break handle (picture 5J). Then, the end of the break cable is broken off (picture 5K).





Picture 4J



Cargo bike enthusiast since 1992

- The cuff, the black thread-bolt and the locking ring are pulled over the break cable (picture 5L) and this is mounted in the break anndle (picture 5M). This is tightened with a 8 mm wrench (picture 5N) and the cuff is puched in place (picture 5O).
- This exercise is repeated for the other break handle.



Picture 4L

Picture 4M





Picture 40

• The bell is mounted - see picture 4P





Page 16

Picture 4P

Cargo bike enthusiast since 1992

• The display is mounted - see picture 4Q og 4R






Picture 4R

• The cables by the handle bar is stripped - see picture 4S

• The front lights are mounted - see picture 4T



Picture 4Q



Picture 4S



Picture 4T



The baggage string is mounted - see picture 4U.

•



Picture 4U

The gear is tested. If the gear "clicks" or you experience difficulties in changing gear, you can ٠ adjust the gear by using the small black "hand-screw" where the gear cable is mounted on the gear shift (picture 4V)



IMPORTANT:

- The frame number is stamped into the crackcase on the left side of the bike. •
- Remember to adjust and re-tighten all moving parts on the bike after some weeks of use. If ٠ re- tightening of the spokes are needed, please use a spoke tightener.
- See our "Let us help" guides on http://www.amcargobikes.co.uk/ •

ENJOY YOUR NEW CARGO BIKE!

