

## ELECTRICAL CARGO BIKE

with mechanical disc breaks



## ASSEMBLE MANUAL

Read and understand these instructions before you begin the assembly. The bike comes partly assembled, and it is important to read the manual carefully before starting assembly, so the bicycle will be assembled in the correct order. It is recommended to be two people to assemble the cargo bike. Be aware that the bike must be re-tightened after approx. 20 km. Make sure to check all parts of the bike and re-tighten all moving parts, including breaks, spokes, bolts and nuts.

## STEP 1: Assembly of the back and front frame

- When the parts have been taken out of the boxes and wrapping, place the front frame upside down on a table or on two chairs (see picture 1A).
- Place the back frame upside down "on top" of the front frame. Avoid taking the plastic on the luggage carrier off to avoid scratches in the paint.
- The main bolt is mounted from below as shown in picture 1B by using a hammer or something similar. It should fit tightly. The bearings should be lubricated with grease. Do not tighten the nut yet.



Picture 1A



Picture 1B

- With the 7 large bolts, washers and nuts mount the bow-shaped and the two straight metal rods as shown on image 1C, 1D and 1E. The metal rods must be placed below the trapezoidal plate and on top of the frame as shown in the pictures. In order to avoid that the stainless steel locknuts get stuck halfway down on the bolt, use some grease at the end of the bolts, before the nut is tightened. Only when these are tightened, tighten the large nut on the main bolt as hard as possible, and insert the split.



- 7 pc. 13 mm bolts (length: 25 mm)
- 7 pc. washers
- 7 pc. 13 mm nuts



**Picture 1C**



**Picture 1D**



**Picture 1E**



**Picture 1F**

## Step 2: Fenders, front wheels and brake pads

- If the bike is assembled using two chairs, one of the chairs is now moved to the end of the front frame and the second chair is removed.
- The front fenders are mounted with 8 small bolts, washers, and nuts + the four brackets (see picture 2A and 2B). To make sure that the fenders are just above the wheels, the nuts are tightened after the wheels are mounted.



- 8 pc. 8 mm bolts (length: 12 mm)
- 8 pc. washers
- 8 pc. 8 mm nuts



**Picture 2A**



**Picture 2B**

- The brake discs are mounted on the front wheels with the 2 x 6 small black torx bolts – see picture 2C.
- Mount the front wheels as in picture 2D.





- 2 pc. break discs
- 2 x 6 small black torx bolts



**Picture 2D**



**Picture 2C**

- The two break calipers are mounted with the 2x2 black umbraco bolts. Notice: use 2-3 ekstra washers per umbraco bolt to ensure a good distance from the end of the bolt to the break disc. Se picture 2E.




- 2 break calibers
- 2x2 black umbraco bolts with 2-3 ekstra washers



**Picture 2E**



**Picture 2F**



**Picture 2G**

- The position of the brake calipers versus the brake discs are adjusted via the blank umbraco-disc on the outside of the caliper and the side-by-side adjustment bolts on the brake caliper – see picture 2F and 2G. The brake discs should in this way run freely without touching the brake pads when the wheel is turned. It is however OK if there is a small "whisling" sound from the brake when the wheel is turned – this will disappear after a few days of use.
- Then the bike is turned (see picture 2H).



**Picture 2H**



## Step 3: Assemble the box

- The corner brackets for the box are mounted as shown in picture 3A – with the nuts on the inside.
- The correct position of the four different corner fittings is shown on picture 3B.



- 8 pc. 10 mm bolts  
(length 30 mm)
- 8 pc. washers
- 8 pc. 10 mm lock nuts



**Picture 3A**



**Picture 3B**

The following is mounted loosely and tightened in the end:

- The front and back panels are mounted (see picture 3C) with 12 of the 10 mm bolts, washers and rounded nuts as illustrated below – with the nuts on the outside.
- The side panels are mounted (see picture 3D) with the remaining 8 of the 10 mm bolts, washers and rounded nuts. The four canopy holders are mounted with the long bolts in the holes in the middle (see picture 3E below). All nuts on the outside.
- The base panel is mounted (see picture 3F) – with the nuts on the underside.

And then all bolts and nuts are tightened.



- 20 pc. 10 mm bolts (length 18 mm)
- 20 pc. washers
- 20 pc. 10 mm rounded nuts



- 4 pc. 10 mm bolts (length 30 mm)
- 4 plastic elements for canopy-mounting
- 4 pc. washers
- 4 pc. 10 mm rounded nuts



Picture 3C



Picture 3D



Picture 3E



- 2 pc. 10 mm bolts (length 70 mm)
- 2 pc. washers
- 2 pc. 10 mm lock nuts
- 2 pc. small bolts
- 2 pc. washers



Picture 3F



- The two step boards and reflectors are mounted (see picture 3G, 3H and 3I).



- 2 pc. step boards
- 4 pc. 10 mm bolts (length 18 mm)
- 4 pc. washers
- 4 pc. 10 mm rounded nuts



- 4 pc. yellow side-reflectors
- 2 pc. white front-reflectors
- 4 pc. red back-reflectors



Picture 3G



Picture 3H



Picture 3I

## Step 4: The rest of the equipment

- The headlights are mounted on the sides of the box (see picture 4A) with the last two 8 mm bolts (same type as for the front fenders).



Picture 4A

- The pedals are mounted (see picture 4B) – note that they have left-thread and that the pedals have left / right markings.



Picture 4B

- The four bolts securing the bearings for the child seats are mounted (see picture 4C).
- The child seats are mounted with four screws (see picture 4D). The seat belts are mounted on the outside of the box (front- and back panel) and below the child seats (see picture 4E).



- 4 pc. 10 mm bolts (length 40 mm)
- 4 pc. washers
- 4 pc. 10 mm lock nuts



Picture 4C



Picture 4D



- 8 pc. 10 mm bolts (length 18 mm)
- 8 pc. washers
- 8 pc. 10 mm lock nuts
- The plastic fittings for the steer and the canopy-holders are mounted with a small hammer (see picture 4F and 4G).
- The plastic-fittings for the wheel nuts are mounted with a small hammer (see picture 4H).



Picture 4E







**Picture 4F**




**Picture 4G**



**Picture 4H**

- The saddle is mounted on the saddle post and this is mounted on the bike (see picture 4I)



**Picture 4I**

- The handlebar is mounted and the break handles, gear shifter, display and bell are mounted on the handlebar (see picture 4J, 4K, 4L, 4M, 4N and 4O).



Picture 4J



Picture 4K



Picture 4L



Picture 4M



Picture 4N



Picture 4O

## Step 5: Brake cables and adjustment of breaks and gear

- The back-break is mounted (ses picture 5A and 5B):
  - The umbraco bolt on the break arm is loosened
  - Make sure that the break pads are in the right position versus the rim on both sides
  - The screws on each side of the break arms are adjusted so that the two arms are equally tight when pushed against the rim
  - Give a couple of mm space to the rim on each side before the umbraco bolt is tightened.
- <https://amladcykler.dk/samle-og-vedligeholdelsesvejledninger/>



Picture 5A



Picture 5B



- The front cables are mounted in the break handle (see picture 5C). They are pulled through the hole in the handle bar (see picture 5D) and through the cable holders (see picture 5E and 5F). The cables are mounted on the break calipers so that the break discs can move freely. It is however OK if there is a small "whisling" sound from the break when the wheel is turned – this will disappear after a few days of use.
- Final adjustment is done partly at the break calipers (see picture 2H and 2I) and partly via the two small blank screws at the break handle (see picture 5C) – until the bike breaks even and effectively.



Picture 5C



Picture 5D



Picture 5E




Picture 5F



Picture 5G

- The gear is tested. If the gear "clicks" or you experience difficulties in changing gear, you can adjust the gear by using the small black "hand-screw" where the gear cable is mounted on the gear shift (see picture 5H).
- <https://amladcykler.dk/samle-og-vedligeholdelsesvejledninger>



Picture 5H

## IMPORTANT!

- The frame number is stamped into the frame on the left side of the bike – just in front of the left pedal.
- Remember to adjust and re-tighten all moving parts on the bike after some weeks of use. If re-tightening of the spokes are needed, please use a spoke tightener.
- See our "Let us help" guides on [www.amladcykler.dk](http://www.amladcykler.dk).

## ENJOY YOUR NEW CARGO BIKE!

